



🏠 18/51-55 Centre Way, Croydon South, VIC
☎ (03) 9761 5233
✉ sales@cccpolishedconcrete.com.au
🌐 www.cccpolishedconcrete.com.au

Site Information

1st Stage - of grinding (pre-cut and seal) needs to occur 5 – 9 days after the pour. This must be completed before any other construction work begins. **(Based on 100m2 – allow 2 days).**

2nd Stage - we return at plaster stage, prior to skirting boards and joinery being fitted, also before stairs if possible. **If there are to be no skirting boards or P50 is being used, we need to return EARLIER.** This is to minimise any risk of damage, ensure the best finish and is a cost saving exercise for the client, as additional time may be required to work around joinery etc. **(Based on 100m2 – allow 3 days).**

3rd Stage - Prior to occupation wash the floor with Tough Green (PH neutral cleaner) as specified on our Maintenance sheets.

Just a reminder, it is imperative that plastic is NOT used after 2nd stage to cover the slab. Plastic will cause the concrete to "sweat" which can cause blotching. Layers of carpet OUTSIDE main traffic areas, signs acting as a reminder that the slab is going to be the finished floor and breathable materials such as Ram board or cloth painter's drop sheets are recommended.

Naturally all jobs are different. Polished Concrete requires a lot more work than grind and seal, which is normally completed closer to the end of the job.

Phone Rick for advice on 0418 553 982 at any stage.