

- 18/51-55 Centre Way, Croydon South, VIC
- **J** (03) 9761 5233
- sales@cccpolishedconcrete.com.au
- www.cccpolishedconcrete.com.au

Concrete Procedures For Optimum Results

The Better The Slab The Better The Job!

Full Exposure

- We grind off 3 5mm.
- Requires stipple finish can be achieved by 1 or 2 passes with the helicopter. CARE MUST BE TAKEN TO ELIMINATE FOOT PRINTS AND SCREED BAR MARKS.

Random Exposure

- We grind off 1 3mm.
- Requires burnished finish, achieved by multiple passes with the helicopter and 1 or 2 quick passes with the
 grinder to remove lumps and bumps. IF THE SLAB IS NOT POURED TO A GOOD FINISH, MORE PASSES
 MAY BE NECESSARY TO GET THE FLOOR TO AN EVEN, LIVABLE FINISH. This will increase the amount of
 exposure, thus cost. CCC Polished Concrete is not responsible for either.

Nil Exposure

- We grind off 1 2mm.
- Requires an absolutely perfect slab. Must be flat and highly burnished. Vibrating the slab evenly assists the
 stone to sink leaving more cream on the surface, reducing the chance of stone being visible. EVEN WITH
 THESE STEPS, THERE IS NO GUARANTEE THAT SOME PEBBLE OR SAND WILL NOT BE EXPOSED. Do not
 pour on a wet or very cold day.

Tips

- 32 MPA.
- F72 (7.2mm) or F82 (8.2mm) mesh placed on "bar stools" in conjunction with 3 x 2m x 18mm rebar rods angled across corners (or to engineers specifications) will help minimise cracking.
- Concreter to ensure adequate strength pump, as mixes can be quite coarse.
- CCC Polished Concrete takes no responsibility for the aggregate exposure achieved. Aggregate exposure is the full responsibility of the concreter or concrete supplier.
- Run an edging tool to all external edges, which helps hold the stones in.

Phone Rick Before you Pour on 0418 553 982